

COAL Lab – 3

Task 1:

Predicted Values:

mov eax, sensorA ; EAX = 120

add eax, sensorB ; EAX = 165


mov ebx, sensorC ; EBX = 30

add ebx, sensorD ; EAX = 48

sub eax, ebx ; EAX = 117

mov result, eax ; result = 117


Screenshot:



Task 2:

Variable Predicted Observed		
<i>holdWater</i> (original)	1840	1840
<i>holdRations</i> (original)	960	960
<i>holdOxygen</i> (original)	275	275
<i>holdParts</i> (original)	88	88
updated water	2110	2110
updated rations	1065	1065
updated oxygen	323	323
updated parts	86	86
<i>totalAfter</i>	3584	3584

Screenshot:



Task 3:

Object TYPE LENGTHOF SIZEOF			
frameID	4	1	4
sensorLog	2	64	128
statusBits	1	16	16
stationName	1	13	13
spare	4	24	96
		Total bytes:	257

3. Add all SizeOF

The observed values were the same as mentioned in the above table.

Adding all sizeof resultantly reveals **257 bytes** of memory which is occupied in the whole process. Since we've 512 bytes of memory available, this model will fit in easily.

4. Quick Answers

- **frameID** is a single DWORD variable with only one value, hence it will only take the size of one element which is **4 bytes**.
- **sensorLog** holds 64 readings but occupies more than 64 bytes but it occupies 128 bytes because it's a DW/WORD type which occupies 2 byte of space per element. Since it's a whole array of 64 elements, it occupies $64 * 2 = \mathbf{128 \text{ bytes}}$
- Removing **0** from end of stationName will remove the null terminator from the end of the string, and since it was an array of BYTE type characters, it will reduce size by **1 Byte**. The type will remain the same but the length and size will reduce by 1 because null terminator is also an element taking up exactly 1 byte memory for being a BYTE type.

Task 4:

# Error code (or “none”) Which rule is broken Corrected line			
1	<code>mov total, countA</code>	Memory to Memory not allowed	<code>mov eax, tota</code> <code>add eax, 25</code> <code>mov total, eax</code>
2	<code>mov eax, limitByte</code>	Register and variable should be same size	<code>limitByte DD 200 ;</code> or <code>DWORD</code> instead of <code>BYTE</code>
3	<code>add 20, al</code>	Wrong instruction	<code>add al, 20</code>
4	<code>mov ebx, SIZEOF slots</code> <code>mov slotCount, ebx</code>	Expects number of elements in slots, we get total size instead	<code>mov ebx,</code> <code>LENGTHOF slots</code>

Screenshot:

